

So easy with ErgoMover...

From delivery to installation

1. ErgoMover picks up stacks of drywall directly from truck




2. Moving inside building with powered wheel drive



Horizontal unloading of stacks of drywall on trestles or vertical unloading of stacks of drywall in ErgoLoader



Picking up plates - ready to install on wall



ErgoMounter installing drywall on steel or wooden frame system



